

1. Insert one AA size battery, Note correct position of positive (+) and negative(-) battery terminals, press "RESET" key.
2. After 3-5 seconds, press "SET" key to display Year, press "UP" or "°C/°F" to set the correct year.
3. Press "SET" key to display Month, press "UP" or "°C/°F" to set the correct month.
4. Press "SET" key to display Date, press "UP" or "°C/°F" to set the correct date.
5. Press "SET" key to display Day, press "UP" or "°C/°F" to set the correct day.
6. Press "SET" key to display time, press "UP" or "°C/°F" to set the correct time.
7. Press "SET" key to complete all the settings The screen will display correct month and date, day and thermometer.