

F6228R

1. Insert one AA size battery, Note correct position of positive (+) and negative(-) battery terminals, press "RESET" key.
2. After 3-5 seconds, press "SET" key to display YR, press "UP" or "DOWN" to set the correct year.
3. Press "SET" key to display Month, press "UP" or "DOWN" to set the correct month.
4. Press "SET" key to display Date, press "UP" or "DOWN" to set the correct date.
5. Press "SET" key to display Day, press "UP" or "DOWN" to set the correct day.
6. Press "SET" key to display 12/24 hours, press "UP" to set the correct 12 or 24 hours.
7. Press "SET" key to display time, press "UP" or "DOWN" to set the correct time.
8. Press "SET" key to complete all the settings The screen will display correct month and date, day and thermometer.
9. Digital time display can only be activated by the touch of the "down" button and than the display of the time will only be reflected for a few seconds.

